

Maxi-Sound Horns
Models 320-2T, 325-2T, X-2000, X-2005, X-2010 & X-2015
INSTALLATION INSTRUCTIONS

Remove the factory horn, and install your new Wolo horn in same position. Fasten securely. If needed, use the mounting bracket that we supply with your new horns.

TWO (2) TERMINAL WIRING

1. In vehicles where the factory wiring connects to two (2) horn terminals. Simply transfer the wires to each Wolo horn. The installation is complete and the horns are ready to be used.


ONE (1) TERMINAL WIRING

In vehicles where the wiring connects to only one (1) horn terminal. Ground one (1) terminal on each of the Wolo horns. Follow the two steps shown below.

1. Using the grounding wire supplied, place the loop end under the mounting bolt of each horn. Firmly tighten to penetrate any paint. The horns must have good ground connection. Attach the connector of grounding wire to a terminal on each horn.

2. Attach the vehicle's horn wires to the vacant terminal on each of the Wolo horns. The installation is now complete and the horns are ready to be used.

Our technicians are available to answer your questions, Monday through Friday from 9 AM to 4 PM EST 1 888-550-Horn (4676)



WARRANTY

Wolo Manufacturing Corporation ("Wolo") warrants to the original purchaser, for three months from the date of purchase, that this product is free from defects in workmanship and materials. If there is such a proven defect, Wolo, at its option, will either repair or replace the item free of charge, if it is returned to Wolo within three months from the date of purchase together with proof of purchase as described below. Wolo reserves the right to inspect any defect prior to settling any warranty claim by repair or replacement. This warranty is limited as above provided and Wolo will not be responsible for fire or other casualty or accident, due to neglect, abuse, abnormal use, modifications, faulty installation of this product, or natural causes.

ANY EXPRESSED WARRANTY NOT PROVIDED HEREIN IS EXCLUDED AND DISCLAIMED. THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY LIMITED TO A TERM OF THREE (3) MONTHS. UNDER NO CIRCUMSTANCES SHALL WOLO BE LIABLE TO PURCHASER OR ANY OTHER PERSON FOR ANY SPECIAL OR CONSEQUENTIAL DAMAGES, WHETHER ARISING OUT OF BREACH OF WARRANTY OR OTHERWISE.

To obtain warranty service, return the product prepaid, and include the original bill of sale showing the date of purchase. Provide with the return a brief description of the problem. Also, include with the return a check or money order in the amount of \$10.00 to cover return shipping. Mail to:

WOLO MANUFACTURING CORP., One Saxwood St., Deer Park, NY 11729

Visit Wolo on the World Wide Web - <http://www.wolo-mfg.com>